



Amazon Fire Hd Safety Controls & settings guide


You can enable restrictions to stop your children from using specific features and applications on the Amazon Fire HD tablet. These parental controls include the ability to prevent purchases from content stores along with access to age-restricted content and the camera to help keep kids safe online.

1 How to activate parental controls


If your child uses an Amazon Fire HD tablet, setting up parental controls is a key part of helping them stay safe online.

To set up parental controls:

Step 1 – From your tablet **home screen**, swipe down from the top and select the **gear icon** next to the profile icon. Under **Personal**, select **Parental Controls**.



Step 2 – Turn them on by **tapping the toggle** to on. You must enter your account **password** to do this, which can also be changed on this page. Now, you can set different parental controls.



2 What are other parental control options

There are a variety of parental controls that you can set up with Amazon Fire HD, including content restrictions, purchases and screen time.

The different types of parental controls are:

Block Amazon content and apps

Adding passwords to access content or change settings

Blocking access to Amazon stores

Requiring passwords for purchases from Amazon Stores or Shop Amazon apps

Sharing content on social media

Limiting access at certain times of day

Monitoring profile activity

