




Xbox One And Xbox One S Parental Controls

Controls & settings guide

Parental Controls for Xbox One X and Xbox One S can be set for each of your children's individual profiles, allowing you to prevent unauthorised purchases, ensuring your children only access age-appropriate content and restrict the ability to chat to strangers online.


1

When on the Xbox one dashboard select 'Settings'



2

Select the 'Privacy & online safety' menu



3

Select 'Child defaults' to restrict all adult content from the user

Or select '**Custom**' to customise the settings for your preference.

Privacy & online safety for HungryGamers

PRIVACY	CONTENT RESTRICTIONS
<input type="radio"/> Child defaults More private	Access to content Appropriate up to age 6
<input type="radio"/> Teen defaults Moderate	Web filtering Turned off
<input checked="" type="radio"/> Adult defaults More social	Descriptions in OneGuide Allow explicit text
<input type="radio"/> Custom	Contact preferences

4 Select 'Use, but customise'

Child privacy & online safety summary


CHILDREN CAN	OTHERS CAN
Children can play and download free games, music, videos, and apps, and make game clips of their best moments.	A child's friends can communicate with them, and see when they're online and available to play.
Children can see other people's profiles, and content they create, but need a parent to add friends.	Microsoft can use the child's video app history to help improve their experiences. Microsoft will store the child's exercise info with their online profiles and keep it private.

Use for HGOffspring Use, but customize

5


There will be a number of default privacy settings you can choose from

Select one and either keep the default settings or customise them to suit your needs.



6

Select 'content & apps' and choose the 'Access to content & apps menu'



7

Choose what age group you want restricted too

